



*Powering Business Worldwide*

Aerospace Group  
Conveyance Systems Division  
Carter® Brand Ground Fueling Equipment

**SM64503**

September 2008

Applicable addition manuals:  
None

**Maintenance & Repair Manual**

---

**3 Inch & 4 Inch Fuel Operated Bypass Pressure Control Valves**

---

**Models 64503 & 64513**

**TABLE OF CONTENTS**

	PAGE
1.0 INTRODUCTION.....	3
2.0 EQUIPMENT DESCRIPTION .....	3
3.0 TABLE OF OPTIONS AND ORDERING INFORMATION .....	3
4.0 DISASSEMBLY .....	4
5.0 INSPECTION .....	6
6.0 REASSEMBLY .....	6
7.0 TEST .....	9
8.0 ILLUSTRATED PARTS CATALOG.....	9
FIGURE 2 - MANIFOLD .....	11
FIGURE 3 - 3.....	12
FIGURE 4 - 4.....	14
FIGURE 5A - INNER PISTON SEAL INSTALLATION - OLDER UNITS.....	16
FIGURE 5B - INNER PISTON SEAL INSTALLATION - NEWER UNITS.....	16
FIGURE 6 - OUTER PISTON SEAL INSTALLATION .....	17

**NOTE:** The information in this manual is to the latest revision of the products listed above at the time of this printing. Eaton reserves the right to change this manual at its discretion.

**Maintenance, Overhaul & Test Instructions  
Eaton's Carter Brand Models 64503 & 64513  
Fuel Operated Bypass Pressure Control Valves**

1.0 INTRODUCTION

This manual furnishes detailed instructions covering the maintenance and overhaul of Carter brand Models 64503, 3 inch and 64513,

4 inch Fuel Operated Bypass Pressure Control Valves and the various options listed in Section 3.0.

2.0 EQUIPMENT DESCRIPTION

Carter brand Models 64503 and 64513 are the latest versions of the 3 and 4 inch Fuel Operated Bypass Pressure Control Valves that replace the older 64133 and 64134 models. Because they have many characteristics in common, a single manual is used to present both units.

The valves listed above are designed to provide a constant nominal pressure at a remote sense point using fuel pressure generated within the system. The valves are direct operating spring loaded piston type valves. When reference fuel pressure is applied to the proper port on the manifold, the fuel control pressure can be increased or decreased by the adjustment knob on the manifold. Deadman control is accomplished using the integral solenoid valves and a deadman switch.

If the valves are to be used at a flow below approximately 100 gpm, the reference pressure may have to be increased to obtain the desired fuel pressure. The reference pressure may vary slightly from unit to unit. Changing the reference pressure is the only way of adjusting fuel discharge pressure.

A minimum line size 3/8 inches should be used as a fuel sense line. Stainless tubing for this line is recommended. If two venturis are used, a three-way valve with at least a 1/4-inch internal orifice should be used to obtain proper surge control.

The opening time of the valve is fixed at the industry standard. It can be changed only by changing a fixed orifice screw in the manifold. Contact Carter for information on obtaining different orifice screws. The check valve under the fuel sense port of the manifold allows restricted flow out of the piston chamber and relatively unrestricted flow into the piston chamber. When a change of approximately 1.5 psi downstream is created, the check valve will open and flood the piston chamber, causing the valve to open rapidly.

The bleeders on the manifold allow bleeding of air from both the fuel sense line and internally within the manifold. The valve should be installed with the bleeders in the upward position to facilitate proper bleeding.

3.0 TABLE OF OPTIONS AND ORDERING INFORMATION

The 64503 and 64513 have common options as listed below.

Carter recommends that at least one end of the valve be flange mounted to the piping system, if both inlet and outlet are Victaulic connections proper bracing must be provided.

**OPTIONS TO BE ADDED TO 64503 or 64513 FUEL OPERATED BYPASS PRESSURE CONTROL VALVES:**

OPTION LETTER	DESCRIPTION	OPTION LETTER	DESCRIPTION
A	Adds 12 VDC Solenoid Valve	E	Adds two Victaulic Adapter Assemblies for use both the inlet and outlet of the unit. (The parts are shipped as loose parts to be used on either end). Mounting fasteners are not provided.
B	Adds 24 VDC Solenoid Valve		
D	Adds one Victaulic Adapter Assy for use on either the inlet or outlet of the unit. (The parts are shipped as loose parts to be used on either end). Mounting fasteners are not provided.	F	Adds Relief Valve Caps.

Example: 64503AD – Basic 3" Fuel Operated Bypass Pressure Control Valve with a kit of parts to convert the standard ASA flange on either end to mate a Victaulic fitting and 12 VDC Solenoid Valve.

64503BE - Basic 3" Fuel Operated Bypass Pressure Control Valve with a kit of parts to convert the standard ASA flange both ends to mate Victaulic fittings and 24 VDC Solenoid Valve.

## 4.0 DISASSEMBLY

- 4.1 64503 & 64513 Valve – Note that due to the similarity between the units, this manual covers both units. The appropriate part numbers for the same type of part are noted Section 8.0.

Refer to Figure 1 for this operation. The valve consists of two basic items, the Valve Assembly (1-1) and the Manifold Assembly (1-2). If a Victaulic fitting is present on the outlet of the valve assembly remove it. Discard the o-ring (from a Carter furnished fitting) or the gasket that is used to seal the fitting to the valve.

- 4.2 MANIFOLD ASSEMBLY - Refer to Figure 2. Remove the Manifold Assembly (1-2) from the unit by removing Screw (2-15) and pulling the manifold from the unit being careful to not lose any of the four Retainers (2-13). Discard O-rings (2-14) when removed.

**Note:** Repairs to the Manifold Assembly (1-2) can be accomplished without removing the main valve from the vehicle system. Be sure that the pressure is relieved before doing this.

- 4.2.1 Remove Housing Check Valve (2-6) and then remove all of the internal parts contained by it. Remove and discard O-rings (2-4) and (2-5).

- 4.2.2 Do not remove Bleeder Assemblies (2-12) unless one or the other is to be replaced due to leakage from its threaded fastener or from the bleeder valve itself. If either are removed, it can be disassembled by removing the Retainer Ring (2-12F) with the proper pliers and all other parts will then come out.

- 4.2.3 Unless there is leakage apparent between the solenoids and manifold, it is not necessary to remove the solenoid valves. To remove the Solenoid Valves (2-17) and (2-18) first unscrew the connector retaining screws on the top of the solenoid assemblies. This will provide access to the two screws holding each of the solenoids to the manifold. There are three O-rings (2-19) on each solenoid used to seal the interfaces between the solenoid and the manifold. Remove and discard them.

- 4.2.4 Do not remove Orifice Screw (2-10) unless it is to be replaced to change the opening time.

- 4.2.5 Do not remove either of the Relief Valves (2-9) unless there is a problem with one of them. If either Relief Valve (2-9) needs servicing and is lock wired to Screw (2-16) cut the wire. Do not remove Screw (2-16) it is used only to safety the relief valve to stop tampering. Remove and discard the entire assembly.

- 4.2.6 Remove Screw (2-8) and O-ring (2-7) and discard the O-ring.

- 4.3 3" VALVE ASSEMBLY – Refer to Figure 3 for this operation.

- 4.3.1 Rotate Outer Piston (3-25) to access 4 Screws (3-5) these screws are a self locking type screws that utilize a nylon insert in the threads to affect resistance and keep the screw locked in place. They can be reused a number of times before losing their locking ability. Using a torque wrench, remove the screws. If the torque is less than 2 inch lbs. replace during reassembly.

- 4.3.2 Discard O-Rings (3-8).

- 4.3.3 Grasp Outer Piston (3-25) and remove the entire piston/shaft assembly from the outlet of the valve.

- 4.3.4 Remove and discard O-rings (3-7) and (3-6) from the shoulder and groove of the Piston Retainer (3-21).

### **WARNING:**

Before proceeding further beware that the outer piston and attaching parts are heavily spring loaded and a vise or similar should be used to safely disassemble the piston assembly.

- 4.3.5 As indicated above, a vise or woodworkers clamp is required to proceed further. Wood blocks should be used to secure the piston

Assemble such that an axial load is exerted yet allows access to both Nuts (3-16).

### **NOTE:**

Shaft (3-27) and nut (3-16) are both stainless steel. Nut (3-16) also includes a locking element. Due to this combination there is the possibility when these items are disassembled that the threads may gall or become damaged beyond repair. If it is necessary to disassemble these items replace both nuts (3-16) and consider replacing the shaft (3-27).

### **CAUTION:**

Be certain the piston assembly is securely held in place and cannot slip, allowing the unit to forcibly separate when the first nut (3-16) is removed. Forcible separation may cause personal injury. Be careful not to damage the sealing surface of the inner or outer piston.

- 4.3.6 With the assembly securely clamped in place, carefully remove Nut (3-16) from the piston assembly, use Lockease or similar as an aid in removing the nut. Remove Washer (3-17) from piston assembly. Slowly open the clamping device allowing the spring force to cause the inner piston assembly to follow the clamp until all spring force is relieved. Then carefully remove the clamp and lift the Inner Piston (3-20) from the Spring (3-26). Remove the two bronze Washers (3-29) from the Inner Piston (3-20) then remove Spring (3-26) and Teflon Washer (3-30) from the Guide (3-22). Remove O-ring (3-18) and Washer (3-19) from the end of Shaft (3-27). Discard O-ring (3-18).
- 4.3.7 Using two thin 3/8-24 UNF-2B nuts as jam nuts on the shaft (3-27) where Nut (3-16) was removed above, remove Nut (3-16) and Washer (3-17) retaining the outer Piston (3-25) from the Shaft (3-27).
- 4.3.8 Remove Screws (3-28) from the spring Guide (3-22) to remove Seal (3-23) and O-ring (3-24) from retainer. Discard O-ring (3-24).
- 4.3.9 On older versions of the 3" valve, it will be necessary to remove Screws (3-12) and remove Seal Housing (3-11) from Body (3-1). Remove and discard O-ring (3-13).
- 4.3.10 Remove and discard Seal (3-10) and O-ring (3-9).
- 4.3.11 Remove Screws (3-14) and then pull out Seal Housing Retainer (3-4) and Housing (3-15) with Seals (3-2) and O-rings (3-3). Discard Seals (3-2) and O-rings (3-3).
- Note: It is recommended the user upgrade to the new seal cartridge. The new design with the energized Seal (3-2) and O-Ring (3-3) are included in the overhaul kit KD64500-5. These seals will not work with the old-style cartridge. Request a -8 kit for hardware items (3-4 & 3-15) to complete the upgrade. This configuration provides a more robust seal, reducing leakage and frequency for overhaul of the seal cartridge.**
- 4.3.12 Older Units Seal Cartridge: Remove Screws (3-14) and then pull out Seal Housing (3-4A). Then remove and discard Seals (3-15A) and O-rings (3-2A) and (3-3).
- 4.3.13 Newer versions are equipped with a Set-Screw (3-36). It is not necessary to remove this screw.
- 4.4 4" VALVE ASSEMBLY – Refer to Figure 4 for this operation.
- 4.4.1 Rotate Outer Piston (4-25) to access 4 Screws (4-5) these screws are a self locking type screws that utilize a nylon insert in the threads to affect resistance and keep the screw locked in place. They can be reused a number of

times before losing their locking ability. Using a torque wrench, remove the screws. If the torque is less than 2 inch lbs. replace during reassembly. Remove the four Screws (4-5) and Washers (4-8).

- 4.4.2 Grasp Outer Piston (4-25) and remove the entire piston/shaft assembly from the outlet of the valve.
- 4.4.3 Remove and discard O-rings (4-7) and (4-6) from the shoulder and groove of the Piston Retainer (4-21).

**WARNING:**

Before proceeding further beware that the outer piston and attaching parts are heavily spring loaded and a vise or similar should be used to safely disassemble the piston assembly.

- 4.4.4 As indicated above, a vise or woodworkers clamp is required to proceed further. Wood blocks should be used to secure the piston.

Assemble such that an axial load is exerted yet allows access to both Nuts (4-16).

**NOTE:**

Shaft (4-27) and nut (4-16) are both stainless steel. Nut (4-16) also includes a locking element. Due to this combination there is the possibility when these items are disassembled that the threads may gall or become damaged beyond repair. If it is necessary to disassemble these items replace both nuts (4-16) and consider replacing the shaft (4-27).

**CAUTION:**

Be certain the piston assembly is securely held in place and cannot slip, allowing the unit to forcibly separate when the first nut (4-16) is removed. Forcible separation may cause personal injury. Be careful not to damage the sealing surface of the inner or outer piston.

- 4.4.5 With the assembly securely clamped in place, carefully remove Nut (4-16) from the piston assembly, use Lockease or similar as an aid in removing the nut. Remove Washer (4-17) from piston assembly. Slowly open the clamping device allowing the spring force to cause the inner piston assembly to follow the clamp until all spring force is relieved. Then carefully remove the clamp and lift the Inner Piston (4-20) from the Spring (4-26). Remove the two bronze Washers (4-29) from the Inner Piston (4-20) then remove Spring (4-26) and Teflon Washer (4-30) from the Guide (4-22). Remove

- O-ring (4-18) and Washer (4-19) from the end of Shaft (4-27). Discard O-ring (4-18).
- 4.4.6 Using two thin 3/8-24 UNF-2B nuts as jam nuts on the shaft (4-27) where Nut (4-16) was removed above, remove Nut (4-16) and Washer (4-17) retaining the outer Piston (4-25) from the Shaft (4-27).
  - 4.4.7 Remove Screws (4-28) from the spring Guide (4-22) to remove Seal (4-23) and O-ring (4-24) from retainer. Discard O-ring (4-24).
  - 4.4.8 Remove and discard Seal (4-10) and O-ring (4-9).
  - 4.4.9 Remove Screws (4-14) and then pull out Seal Housing Retainer (4-4) and Housing (4-15) with Seals (4-2) and O-rings (4-3). Discard seals (4-2) and O-rings (4-3).

**Note: It is recommended the user upgrade to the new seal cartridge. The new design with the energized Seal (4-2) and O-Ring (4-3) are included in the overhaul kit KD64500-6. These seals will not work with the old-style cartridge. Request a -8 kit for hardware items (4-4 & 4-15) to complete the upgrade. This configuration provides a more robust seal, reducing leakage and frequency for overhaul of the seal cartridge.**

- 4.4.10 Older Units Seal Cartridge: Remove Screws (4-14) and then pull out Seal Housing (4-4A). Then remove and discard Seals (4-15A) and O-rings (4-2A) and (4-3).
- 4.4.11 Newer versions are equipped with a Set-Screw (4-36). It is not necessary to remove this screw.

5.0 **INSPECTION**

It is recommended that all O-rings and seals be replaced at every overhaul. Inspect all metal parts for dings, gouges, abrasions, etc. On the inner and outer piston use 320 grit paper to remove any sharp edges if required be careful not to remove the hard anodize finish on these pistons. Check the knife-edge of the outer piston where it meets O-ring (3-7 or 4-7). This edge should be smooth and free of any imperfections. If any imperfections are found that cannot be polished from the

surfaces or the knife-edge the part should be replaced.

Inspect all metal parts for dings, gouges, abrasions, etc. Use 320 grit paper to smooth and remove sharp edges. Replace any part with damage exceeding 15% of local wall thickness. Use alodine 1200 to touch up bared aluminum.

Note: Nuts (3-16) & (4-16) should not be reused.

6.0 **REASSEMBLY**

Reassembly is accomplished in essentially the reverse order of disassembly. A light coat of petroleum jelly may be used during overhaul but do not use any other type of lubricant, **ONLY PETROLEUM JELLY.**

Note: Lightly lubricate all O-rings except O-Ring (3-9) or (4-9) and O-Ring (3-2A) or (4-2A) [old seal cartridge design] to be installed dry).

- 6.1 Make certain all components are clean and free from oil, grease, or any other corrosion resistant compound on all interior or exterior surfaces. Wash all parts with cleaning solvent, Federal Specification P-D-680, and dry thoroughly with a clean, lint-free cloth or compressed air.

**WARNING:**  
Use cleaning solvent in a well-ventilated area. Avoid breathing of fumes and excessive solvent contact with skin. Keep away from open flame.

- 6.2.1 Seal Cartridge older units: Place O-rings (3-3) into the grooves of the Seal Housing (3-4A) outside diameter. Install O-rings (3-2A) in o-ring grooves on inside diameter of Housing. DO NOT LUBRICATE. Next install Piston Seals (3-15A) in inside diameter grooves over O-rings (3-2A) per Figure 5A. Smooth the combination of the Seal and O-ring (3-2A) with the finger to assure that they are installed completely in the seal grooves. Apply a light coat of lube and then insert the assembly into the main Housing (3-1) with the "notch" on (3-4A) oriented as shown on Figure 3.
- 6.1.2 Install Screws (3-14) and torque to 18 ± 2 in.-lb. (21 ± 2 kg-cm). Condition seals with seal run-in tool AF42208-1 [use instructions from the SM64800 manual.]

**Note: It is recommended the user upgrade to the new seal cartridge. The new design with the energized Seal (3-2) and O-Ring (3-3) are included in the overhaul kit KD64500-5. These seals will not work with the old-style cartridge. Request a -8 kit for hardware items (3-4 & 3-15) to complete the upgrade. This configuration provides a more robust seal, reducing leakage and**

- 6.2 3" VALVE ASSEMBLY- Refer to Figure 3 for this operation.

**frequency for overhaul of the seal cartridge.**

- 6.2.3 Seal Cartridge newer units: O-rings (3-3) should be fitted onto the grooves of Seal Housing (3-15). The lubricated Inner Piston Seals (3-2) should be installed on the inside diameter of the Seal Housing (3-15) per Figure 5B. Now insert the assembly into the main Housing (3-1) with the "notch" on (3-4) oriented as shown on Figure 3. Be careful not to damage the seals during installation.
- 6.2.4 Install the Seal Housing Retainer (3-4) into the main Housing (3-1) by installing Screws (3-14). Torque Screws (3-4) to  $18 \pm 2$  in.-lb. ( $21 \pm 2$  kg-cm). When properly installed, it is not necessary to polish the new type seals.
- NOTE:**  
Shaft (3-27) and nut (3-16) are both stainless steel. Nut (3-16) also includes a locking element. Due to this combination there is the possibility when these items are disassembled that the threads may gall or become damaged beyond repair. If it is necessary to disassemble these items replace both nuts (3-16) and consider replacing the shaft (3-27).
- 6.3 Assemble Outer Piston (3-25) onto Shaft (3-27) using Washer (3-17) and Nut (3-16). Use two thin nuts 3/8-24 UNF-2B nuts as jam nuts on the opposite end of the Shaft (3-27) and tighten the Nut (3-16)  $195 \pm 10$  in.-lb. ( $225 \pm 12$  kg-cm).
- 6.3.1 Install O-ring (3-24) on Seal (3-23) and install in Retainer (3-21). The leg or hook end of the seal should point toward the Outer Piston (3-25). Press the seal into place very carefully in the retainer. Install Screws (3-28) through spring Guide (3-22) and tighten screws equally.
- 6.3.2 Apply a light coat of lube to inside ID of Seal (3-23) and slide the Retainer (3-21) onto Shaft (3-27).
- 6.3.3 Install Teflon Washer (3-30) on the shoulder of the spring Guide (3-22).
- 6.3.4 Place Washer (3-19) over the end of the Shaft (3-27) and install O-ring (3-18) above the washer.
- 6.3.5 Install Spring (3-26) onto Guide (3-22). Place the two bronze Washers (3-29) on top of the spring and hold them in place by placing the Inner Piston (3-20) over Spring (3-26). Insert assembly into the clamping device used during disassembly. Compress the assembly and allow access to install the Washer (3-17) and Nut (3-16) on the end of the shaft and tighten to  $195 \pm 10$  in.-lb. ( $225 \pm 12$  kg-cm).
- 6.3.6 Install the O-ring (3-6) into groove in Retainer (3-21). Install O-ring (3-7) over the end of the Retainer (3-21) to where it rests against the retainer's shoulder.
- 6.3.7 Insert the non-lubricated O-ring (3-9) into the groove in the outlet of Housing (3-1) Install Seal (3-10) over O-ring (3-9) (Refer to Figure 6).
- 6.3.8 On older versions, if equipped, place O-ring (3-13) over Retainer (3-11) and install the assembly into the main housing fully without cutting the O-ring (3-13). Rotate the retainer to line up the four holes with the mating holes in the housing and install Screws (3-12).
- 6.3.9 Insert piston assembly into the housing and rotate Outer Piston (3-25) to line up the four holes with the mating holes in the housing. Place O-rings (3-8) over Screws (3-5) and tighten in a cross manner.
- 6.3.10 On newer units with a Set-Screw (3-36) ensure the screw has not become loose and remains snug in the housing.
- 6.4 4" VALVE ASSEMBLY - Refer to Figure 4 for this operation.
- 6.4.1 Seal Cartridge older units: Place O-rings (4-3) into the grooves of the Seal Housing (4-4A) outside diameter. Install O-rings (4-2A) in O-ring grooves on inside diameter of Housing. DO NOT LUBRICATE. Next install Piston Seals (4-15A) in inside diameter grooves over O-rings (4-2A) per Figure 5A. Smooth the combination of the Seal and O-ring (4-2A) with the finger to assure that they are installed completely in the seal grooves. Apply a light coat of lube and then insert the assembly into the main Housing (3-1) with the "notch" on (4-4A) oriented as shown on Figure 3.
- 6.4.2 Install Screws (4-14) and torque to  $18 \pm 2$  in.-lb. ( $21 \pm 2$  kg-cm). Condition seals with seal run-in tool AF42208-1 [use instructions from the SM64800 manual.]
- Note: It is recommended the user upgrade to the new seal cartridge. The new design with the energized Seal (4-2) and O-Ring (4-3) are included in the overhaul kit KD64500-6. These seals will not work with the old-style cartridge. Request a -8 kit for hardware items (4-4 & 4-15) to complete the upgrade. This configuration provides a more robust seal, reducing leakage and frequency for overhaul of the seal cartridge.**
- 6.4.3 Seal Cartridge newer units: O-rings (4-3) should be fitted onto the grooves of Seal Housing (4-15). The lubricated Inner Piston Seals (4-2) should be installed on the inside diameter of the Seal Housing (4-15) per Figure 5B. Now insert the assembly into the main

- Housing (4-1) with the “notch” on (4-4) oriented as shown on Figure 3. Be careful not to damage the seals during installation.
- 6.4.4 Install the Seal Housing Retainer (4-4) into the main Housing (4-1) by installing Screws (4-14). Torque Screws (4-4) to  $18 \pm 2$  in.-lb. ( $21 \pm 2$  kg-cm). When properly installed, it is not necessary to polish the new type seals.

**NOTE:**

Shaft (4-27) and nut (4-16) are both stainless steel. Nut (4-16) also includes a locking element. Due to this combination there is the possibility when these items are disassembled that the threads may gall or become damaged beyond repair. If it is necessary to disassemble these items replace both nuts (4-16) and consider replacing the shaft (4-27).

- 6.4.5 Assemble Outer Piston (4-25) onto Shaft (4-27) using Washer (4-17) and Nut (4-16). Use two thin nuts 3/8-24 UNF-2B nuts as jam nuts on the opposite end of the Shaft (4-27) and tighten the Nut (4-16)  $195 \pm 10$  in.-lb. ( $225 \pm 12$  kg-cm).
- 6.4.6 Install O-ring (4-24) on Seal (4-23) and install in Retainer (4-21). The leg or hook end of the seal should point toward the Outer Piston (4-25). Press the seal into place very carefully in the retainer. Install Screws (4-28) through spring Guide (4-22) and tighten screws equally.
- 6.4.7 Apply a light coat of lube to inside ID of Seal (4-23) and slide the Retainer (4-21) onto Shaft (4-27).
- 6.4.8 Install Teflon Washer (4-30) on the shoulder of the spring Guide (4-22).
- 6.4.9 Place Washer (4-19) over the end of the Shaft (4-27) and install O-ring (4-18) above the washer.
- 6.4.10 Install Spring (4-26) onto Guide (4-22). Place the two bronze Washers (4-29) on top of the spring and hold them in place by placing the Inner Piston (4-20) over Spring (4-26). Insert assembly into the clamping device used during disassembly. Compress the assembly and allow access to install the Washer (4-17) and Nut (4-16) on the end of the shaft and tighten to  $195 \pm 10$  in.-lb. ( $225 \pm 12$  kg-cm).
- 6.4.11 Install the O-ring (4-6) into groove in Retainer (4-21). Install O-ring (4-7) over the end of the Retainer (4-21) to where it rests against the retainer's shoulder.
- 6.4.12 Insert the non-lubricated O-ring (4-9) into the groove in the outlet of Housing (4-1) Install Seal (4-10) over O-ring (4-9) (Refer to Figure 6).
- 6.4.13 Insert piston assembly into the housing and rotate Outer Piston (4-25) to line up the four holes with the mating holes in the housing. Place Washers (4-8) over Screws (4-5) and tighten in a cross manner.
- 6.4.14 On newer units with a Set-Screw (4-36) ensure the screw has not become loose and remains snug in the housing.
- 6.5 MANIFOLD ASSEMBLY
- 6.5.1 Assemble in the reverse order.
- 6.5.2 Place O-ring (2-7) over Screw (2-8) and install.
- 6.5.3 If either of the Relief Valves (2-9) was removed then install a new one. After the Relief Valve(s) has been adjusted, during flow testing, safety wire the valve to the Screw (2-16) to prevent tampering.
- 6.5.4 If for some reason the Orifice Screw (2-10) was removed then reinstall it at this time.
- 6.5.5 If Solenoids (2-17) or (2-18) were removed, first secure the O-rings (2-19) to the bottom of the Solenoid Valves (2-17) or (2-18) by applying a small amount of petroleum jelly to the bottom of the valve to help hold the interface o-rings in place, then install solenoids on the Manifold (2-1) using the solenoid mounting screws. Mount the connectors onto the solenoids and secure in place by use of the connector retaining screws.
- 6.5.6 If either bleed valve was disassembled begin by placing O-ring (2-12C) over the Poppet (12B). Lay Plug (2-12A) upside down and insert assembled (2-12B) [Reference Figure 2]. Place Spring (2-12D) over the shaft of Poppet (2-12B). Place the Washer (2-12E) on the Spring (2-12D). Compress assembled unit thus far and use snap or lock ring pliers to separate the Retainer (2-12F) and install in the retainer groove on the inside diameter of the bleeder Plug (2-12A).
- 6.5.7 Use a product similar to Vibra Seal (2-11) on the pipe threads on item(s) (2-12A) and install Bleeder Assembly (2-12) in bleeder port(s) of manifold.

**NOTE:**

Do not use Teflon tape on any threads in this product. Loose pieces of tape can cause failure of the product.

- 6.5.8 If check valve was disassembled begin by placing Spring (2-2) into the cavity marked “fuel”. Next, place O-ring (2-5) over the top of the Check Valve (2-3) and place over the spring. Install Gasket (2-4) onto the Check Valve Housing (2-6) and install in the fuel port of the manifold.

6.5.9 Be careful to install Retainers (2-13) and O-rings (2-14) in the proper places. One may use a coating of petroleum jelly to hold them in place while assembling the manifold to the main valve.

6.5.10 Place the manifold assembly onto the valve and retain with Screw (2-15) tightening to hold securely in place.

## 7.0 TEST

7.1 The following test procedures will be accomplished after overhaul:

### 7.2 TEST CONDITIONS

Test media shall be JP-8 MIL-T-83133, Jet A, an odorless kerosene or Stoddard type solvent MIL-PRF-7024E Type II.

#### **BLEEDING VALVE!**

Before testing or use the valve must be bled of all trapped air. After pressurizing the unit, use a plastic rod to depress Poppet (2-12B) with a rag around the unit to absorb fuel flow from the bleeder. This should be done long enough to assure all trapped air is exhausted from the valve.

### 7.3 VALVE BODY AIR-TIGHTNESS TEST

Note that the various ports noted below are identified by engraved markings, "TO PUMP INLET", "FUEL", VENTURI PRESSURE ADJ, PUMP PRESSURE ADJ. and "BLEED".

7.3.1 Adjust the Venturi Pressure Adjustment and Pump Pressure Adjustment regulators such that they are fully closed.

7.3.2 Apply 60-psi air pressure to the inlet to open the valve. Fill the valve through the inlet with test fluid while bleeding air from the outlet

fitting. Rotate the valve such that outlet is the highest point. After the valve is bled from the outlet press on the BLEED valve located towards the outlet to bleed trapped air.

7.3.3 Pressurized the valve inlet, FUEL port and outlet simultaneously to 120-psi with both solenoids de-energized. Maintain pressure for one minute while visually inspecting for indication of external leakage. None should be apparent. Energize both solenoids, maintain the pressure for one minute and check for external leakage. None shall be apparent.

7.3.4 Repeat the test in 7.3.3 at 4-6 psi.

7.3.5 Release internal pressure and drain the test fluid.

### 7.4 FUNCTIONAL TEST


Testing for functionality can be accomplished on the vehicle unless there is a complete test rig available. If there is contact Carter for more details on how to test for full function.

Adjustment of the pressure at the Venturi is accomplished by using the integral regulator on the side of the manifold. After adjustment is completed, wire lock it to the provided screw to prevent tampering.

## 8.0 ILLUSTRATED PARTS CATALOG

Tables 1.0 – 4.0 tabulate the parts and sub-assemblies comprising the 64503 & 64513 Bypass Pressure Control Valves. The item

numbers of the table are keyed to the exploded views of the nozzle diagrammed in Figures 1 - 4.



**FIGURE 1**  
**FUEL OPERATED BYPASS VALVE ILLUSTRATION**

TABLE 1.0  
Reference Figure 1

Fig.	Item	Part Number	Description	Units/ Assy	Used On	Spares/10 Units/Yr
1	1	47510-2	Valve Assembly – 3" Bypass .....	1	64503	-
		47511-2	Valve Assembly – 4" Bypass .....	1	64513	-
2		47503-1	Manifold Assembly – 12 VDC .....	1	Option A	-
		47503-2	Manifold Assembly – 24 VDC .....	1	Option B	-
3		47512	Victaulic Adapter Assembly – 3" Valves .....	1 or 2	64503D or E	-
4		221596	Victaulic/ANSI Flange Adapter – 3" .....	1	47512	-
5		MS29513-245	O-ring.....	1	47512	10
3		47513	Victaulic Adapter Assembly – 4" Valves .....	1 or 2	64513D or E	-
4		221597	Victaulic/ANSI Flange Adapter – 4" .....	1	47513	-
5		MS29513-255	O-ring.....	1	47513	10

Kits to overhaul the main valve assembly and the manifold are available (see below). If the entire valve is to be overhauled, a minimum of two kits will be required, one for the main valve and one for the manifold assembly.

- KD64500-3 Kit - Contains the parts needed to overhaul the above manifold assembly – contains items 2-4, 2-5, 2-7, 2-12C, 2-14 & 2-19.
- KD64500-5 Kit – Contains the parts needed to overhaul the 47510-2 3" valve assembly – Contains items 3-2, 3-3, 3-6, 3-7, 3-8, 3-9, 3-10, 3-13, 3-18, 3-23 & 3-24.
- KD64500-6 Kit – Contains the parts needed to overhaul the 47511-2 4" valve assembly – Contains items 4-2, 4-3, 4-6, 4-7, 4-9, 4-10, 4-18, 4-23 & 4-24.
- KD64500-7 Kit – Contains the interface O-rings used on the Victaulic Adapters option D or E. Contains items- 1-5 for both 3" and 4" adapters.
- KD64500-8 Kit – Contains the housing and retainer necessary to upgrade to the now standard seal cartridge design. Contains items – 3-4 and 3-15 (or 4-4 and 4-15).





Figure 2 - MANIFOLD PARTS BREAKDOWN

TABLE 2.0  
Manifold used on the 64503 & 64513  
Reference Figure 2

Fig.	Item	Part Number	Description	Units/ Assy	Option	Spares/10 Units/Yr
2		47503-1	Manifold, Assembly.....	1	A	-
		47503-2	Manifold, Assembly.....	1	B	-
	1	221583	Manifold.....	1	All	
	2	200791	Spring.....	1	All	
	3	205772	Check Valve.....	1	All	
	4	MS29512-08	Gasket.....	1	All	10
	5	MS29513-009	O-Ring.....	1	All	10
	6	205756-2	Housing, Check Valve.....	1	All	
	7	MS29513-010	O-Ring.....	1	All	10
	8	GF35206-276	Screw.....	1	All	
	9	47454	Relief Valve.....	2	All	
	10	29224-2	Orifice Screw.....	1	All	-
	11	503*	Vibra- Seal (or equal).....	AR	All	
	12	47414	Bleeder.....	2	All	-
	12A	221554	Plug.....	2	All	-
	12B	26664	Poppet.....	2	All	-
	12C	201201-006	O-Ring.....	2	All	20
	12D	222047	Spring.....	2	All	-
	12E	5710-152-30	Washer.....	2	All	-
	12F	N5000-31-H	Retainer.....	2	All	-
	13	221592	Retainer.....	4	All	
	14	MS29513-012	O-Ring.....	4	All	10
	15	GF16997-109	Screw.....	1	All	
	16	NAS1352C08H4	Screw.....	2	All	
	17	47455-2	Solenoid Valve – 12 VDC.....	1	A	-
	17	47455-4	Solenoid Valve – 24 VDC.....	1	B	-
	18	47455-1	Solenoid Valve – 12 VDC.....	1	A	-
	18	47455-3	Solenoid Valve – 24 VDC.....	1	B	-
	19	100004B	O-Ring.....	6	All	60
	20	222104	Cap, Valve.....	2	F	-

\* DO NOT USE TEFLON TAPE!



**Figure 3**  
**47510-2 3" Valve Assembly**  
**Used on 64503**

TABLE 3.0  
 3" Valve Assembly  
 Used on 64503  
 Reference Figure 3

Fig.	Item	Part Number	Description	Units/ Assy	Spares/10 Units/Yr
3		47510-2	Valve Assembly 3".....	1	1
	1	47506	Valve Housing, 3" .....	1	-
	2	222165	Seal, Inner Piston .....	2	10
	2A	MS29513-129	O-Ring .....	2	10
	3	MS29513-134	O-Ring .....	2	10
	4	222161	Retainer, Seal Housing.....	1	-
	4A	221307	Seal Housing .....	1	-
	5	220685-1250	Screw.....	4	-
	6	MS29513-038	O-Ring .....	1	10
	7	201201-231	O-Ring .....	1	10
	8	MS29513-008	O-Ring .....	4	10
	9	MS29513-151	O-Ring .....	1	10
	10	220665	Seal, Outer Piston.....	1	10
	11	221193	Seal, Housing .....	1	-
	12	GF16997-18	Screw .....	6	-
	13	MS29513-042	O-Ring .....	1	10
	14	GF16997-32L	Screw.....	4	-
	15	222160	Housing, Seal .....	1	-
	15A	200758	Seal, Inner Piston .....	2	10
	16-30	47508-2	Piston Assembly 3".....	1	1
	16	38NST188	Nut Self-locking.....	2	20
	17	GF960C616L	Flat Washer .....	2	-
	18	MS29513-012	O-Ring .....	1	10
	19	202291	Washer .....	1	-
	20	200759	Inner Piston.....	1	-
	21	221593	Seal Retainer .....	1	-
	22	221594	Guide .....	1	-
	23	221595	Seal, Piston Shaft .....	1	10
	24	203565	O-Ring .....	1	10
	25	220666	Outer Piston.....	1	-
	26	220005	Spring .....	1	-
	27	202290	Shaft .....	1	-
	28	NAS1351C04-4	Screw.....	6	-
	29	5720-158-25	Washer, Bronze .....	2	-
	30	5610-381-50	Washer, Teflon .....	1	-
	31-35	Left intentionally blank			
	36	AN565AC624H8	Set Screw .....	1	-




Figure 4

47511-2 4" Valve Assembly  
Used on 64513

TABLE 4.0  
4" Valve Assembly


Used on 64513


Reference Figure 4

Figure	Item	Part Number	Description	Units / Assy	Spares/10 Units/Yr
4		47511-2	Valve Assembly, 4".....	1	1
	1	47507	Housing Assembly.....	1	-
	2	222165	Seal, Inner Piston .....	2	10
	2A	MS29513-129	O-Ring.....	2	10
	3	MS29513-134	O-Ring.....	2	10
	4	222161	Retainer, Seal Housing .....	1	-
	4A	221307	Seal Housing.....	1	-
	5	LP51958-64	Screw .....	4	-
	6	MS29513-149	O-Ring.....	1	10
	7	201201-240	O-Ring.....	1	10
	8	NAS620C10L	Washer.....	4	-
	9	MS29513-155	O-Ring.....	1	10
	10	200754	Seal .....	1	10
	11-13	Left intentionally blank			
	14	GF16997-32L	Screw .....	4	-
	15	222160	Housing, Seal.....	1	-
	15A	200758	Seal, Inner Piston.....	2	10
	16-30	47509-2	Piston Assembly.....	1	1
	16	38NST188	Nut, Self-locking .....	2	20
	17	GF960C616L	Washer.....	2	-
	18	MS29513-012	O-Ring.....	1	10
	19	202291	Washer.....	1	-
	20	200759	Inner Piston .....	1	-
	21	221598	Seal Retainer .....	1	-
	22	221594	Guide.....	1	-
	23	221595	Seal, Piston Shaft.....	1	10
	24	203565	O-Ring.....	1	10
	25	202334	Piston, Outer .....	1	-
	26	220005	Spring.....	1	-
	27	202290	Shaft.....	1	-
	28	NAS1351C04-4	Screw .....	6	-
	29	5720-158-25	Washer, Bronze.....	2	-
	30	5610-381-50	Washer, Teflon.....	1	-
	31-35	Left intentionally blank			
	36	AN565AC624H8	Set Screw.....	1	-

Table 5.0  
Torque Specifications 64503 & 64513

Fig.	Item	Part Number	Description	Torque in.-lb.
3 or 4	14	GF16997-32L	Screw(s) .....	18 ± 2 in.-lb. (21 ± 2 kg-cm)
3 or 4	16	38NST188	Nut(s) .....	195 ± 10 in.-lb. (225 ± 12 kg-cm)





Outer Piston Seal Installation

FIGURE 6

Aerospace Group  
Conveyance Systems Division  
9650 Jeronimo Rd  
Irvine, CA 92618  
Ph (949) 452-9500  
Fax (949) 452-9992



*Powering Business Worldwide*