

**DT Optim 750****Device Parameters Displayed via the Web UI**

---

Parameters	Unit	Trend Graph Available (PXG600 only)
Ia	amperes	Yes
Ib	amperes	Yes
Ic	amperes	Yes
Ig	amperes	No
In	amperes	No
Demand Ia peak	amperes	Yes
Demand Ib Peak	amperes	Yes
Demand Ic Peak	amperes	Yes
Demand Ig Peak	amperes	Yes
Demand In Peak	amperes	Yes
Demand Ia	amperes	Yes
Demand Ib	amperes	Yes
Demand Ic	amperes	Yes
Demand Ig	amperes	Yes
Demand In	amperes	Yes

**Slave Action Commands**

---

Ack Energy Reset  
 Advance to next time stamped trip buffer  
 Reset demand watts window  
 Reset energy  
 Reset INCOM slave interface statistics  
 Reset peak demand currents  
 Reset peak demand watts  
 Reset product specific statistics  
 Reset time stamped trip data buffer  
 Reset trip  
 Snapshot energy command