

Power Xpert Gateway 400E/600E/800E

DT3000

Device Parameters Displayed via the Web UI

Parameters	Unit	Trend Graph Available (PXG600E & 800E only)
Ia	amperes	Yes
Ib	amperes	Yes
Ic	amperes	Yes
Ig	amperes	No
Phase A Peak	amperes	Yes
Phase B Peak	amperes	Yes
Phase C Peak	amperes	Yes
Ground Peak	amperes	Yes
Highload	no-units	No

Slave Action Commands

Acknowledge time stamped event buffer
Reset Alarm
Reset INCOM slave interface statistics
Reset peak demand currents
Reset product specific statistics
Reset time stamped trip data buffer
Reset trip